

Franke Triflow Pressure Controlling And Airlock Inhibiting Device (PCAID) Installation Guide

Switch off heating tank and disconnect plug.

Open HOT side of dispensing head until water runs cold.

Turn off water supply.

Remove existing hose connector from top of tank.

Trim back 'Norprene' tube by 1 inch.

Fit extension to tube, if needed, using barbed connector and 2 hose clips.

Fit PCAID to top of tank and reconnect hose.

Turn on water supply and allow system to fill.

Plug in and switch on heating tank.

Wait 10 to 15 minutes for water to reach optimum temperature.

