
M3

Pressure balance mixing valve




Rough: 289 705 999 (sold separately)

dimensions inches



technical specifications note: xxx represent different finishes

code: 231 606 xxx





www.cifial.pt | cifial@cifial.pt cifial@cifial.es www.cifial.co.uk | sales@cifial.co.uk www.cifialusa.com | info@cifialusa.com

assembly instructions

- 1 Pressure balance rough valve is sold separately.
- 2 Place stem extension onto valve stem.
- 3 Slide face plate assembly into place and engage stem extension into handle drive shaft using face plate screws.
- 4 Set temperature limit ring by turning handle drive shaft counter clockwise until desired maximum temperature (43° c/110°F) is reached. Place limit stop onto handle drive shaft with arm set next to limit stop pin. Turn handle drive shaft clockwise to shut off valve.
- 5 Place handle escutcheon base and handle onto handle drive shaft so that the handle stands in the off position (5 o'clock). Tighten with handle screw and insert handle top.