mr.steam[®]steambaths

Technical Specifications

eTempo[®] Control

BOX CONTENTS:

- eTEMP0[®] Control
- Control Cable (30 ft.)
- Steam head
- Tube of Silicone Sealant
- Owner's Manual

eTEMPO[®] surface-mounts inside the steam/shower enclosure, and is suitable for use with an available eTEMPO/Start[®] control. All eTEMPO controls are standard with solid brass covers in round and square designs. For use with mr.steam steambath Models MS90E-MS400E only. Available in the most popular designer finishes listed below.

Each eTEMP0° control is suitable for use inside or outside the steam/shower enclosure, featuring:

- Solid brass decorative cover with choice of square or round styles in designer finishes
- Digital display for temperature setting
- Programmable temperature
- Includes AromaSteam steamhead in matching finish
- Compatible with eTEMPO/Start
- Soft touch keypad with On/Off modes
- Low voltage operation
- For Models MS90E-MS400E only


The eTEMPO control is designed to be installed inside or outside the steam room but is primarily installed inside the steam room. If the control is installed inside the steam room the control must be located:

- 4-5 feet above the floor
- The control features an integral temperature sensor. Locate the control in a location representative of the desired steam bathing temperatures. Do not locate the control above or near the steam head or direct steam emissions.
- on a vertical wall

The control cable length is 30 feet. Insure that the control and/or steam generator are located accordingly. Contact a Mr.Steam technical service representative if a longer cable is required. Contact Mr.Steam for optional 60 ft. cable, PN 103990-60.

If the control is installed outside the steam room a Remote Temperature Probe Part Number MSTS must be installed inside the steam room.

eTEMPO Controls are available in the following designer finishes: Polished Chrome, Polished Nickel, Brushed Nickel, Satin Nickel, Polished Gold, Satin Gold, Polished Brass, Antque Brass, Oil Rubbed Bronze and Pewter.



NOTE: FOR ILLUSTRATIVE PURPOSES ONLY.

IMPORTANT: See Mr.Steam[®] Installation, Operation and Maintenance Manual, PUR 101289, for details. Click here to download this manual: http://www.mrsteam.com/support/downloads.html